

**Model # 7898**

**UNDERCAR KITS**



## **Deluxe Noid Lite and GM AC Signal Test Lights Set**



### **FEATURES:**

- Economic way to check electronic fuel injection (EFI) signals
- Quickly and easily checks for systems of GM TBI, Bosch PFI Ford TBI, GM PFI, Geo TBI and GM SCPI
- To test, just disconnect the fuel injectors, plug the Noid Lite into injector wiring harness then crank the engine
- Normal voltage is indicated by flashing light which is visible from passenger compartment
- Blow molded case for easy storage and transport

### **SALES AND MARKETING**

401 S. PARK AVENUE  
MONTEBELLO, CA 90640  
(800) 221-9705

Phone: (323) 510-2950 • Fax: (323) 887-1958

### **WAREHOUSE AND OPERATIONS**

372 OLD US HIGHWAY 52 SOUTH  
MT. AIRY, NC 27030  
(800) 221-9705

Phone: (336) 786-6432 • Fax: (336) 786-4992

**E-mail : [astrotools@astrotools.com](mailto:astrotools@astrotools.com)**

**WEBSITE : [www.astrotools.com](http://www.astrotools.com)**